**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.





**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

- Follow installation manual instructions carefully. Installer must careful to not cause interference between Navigator System c abling and active / passive car safety device (Ex: Air bags, seat belts, indicators, etc...)
- Turn OFF the radio.
- Before any attempt of component removal, the installer must disconnect the vehicle battery and isolate the ends of the cable .
- Do not attempt this installation operation if there are missing components. Please check the bill of materials carefully to ensure the kit is complete.
- Installation requires careful attention. If you have concerns about your abilities to perform delicate operations, then do not be egin the installation.
- The car must be secured to not move during installation. Parking brake must be engaged at all times.
- Operation should be made in a clean, safe and well ventilated environment without trip hazards and slippery floors
- Do not install by yourself if you do not have qualifications and/or tools to perform the retrofit. You may damage the car's components and/or the Navigator if not professionally installed.
- Poor installation can result in poor performance, personal injuries and will immediately void the factory warranty.
- Do not install the Navigator in a position that blocks the driver's view or hinders safe vehicle operation.



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

#### Caution

Installation Time is around 3-4 hours with additional time required for options installation

Do NOT RUSH and if issues occur contact technical support



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

#### Table of contents:

1.	Tools Required –	Page 5
2.	Bill of Materials –	Page 6
3.	Cables interconnection identification –	Page 10
4.	Touchscreen Connections identification –	Page 16
5.	TRIP Module connection identification –	Page 20
6.	Vehicle Preparation –	Page 24
7.	Radio Preparation –	Page 35
3.	Vehicle Year Specific instructions	
	a. 2011 Sonata –	Page 38
	b. 2012+ Sonata –	Page 50
9.	Radio Bracket Installation –	Page 63
10.	Touchscreen Fascia Installation –	Page 65
11.	Fascia Trim Preparation –	Page 70
12.	Lower Console Preparation –	Page 77
13.	Electrical Connections –	Page 82
14.	Installation in Vehicle –	Page 96
15.	Appendix 1 – TRIP Module Dip Switches	Page 110
16.	Appendix 2 – Backup Camera Installation	Page 112
17.	Appendix 3 – Parking Assist	Page 115
18.	Appendix 4 – RDS Traffic Tuner	Page 118
19.	Tips & Tricks	Page 121



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

#### Tools required for successful install -#1 = Patience!!!







10mm socket

Shop Towels & Alcohol Gloves
Hacksaw
3M Industrial double sided tape
Knife
Jeweler screw driver set Ratchet

Wire strippers
Torx T15 Driver



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

#### Bill of materials



Aux cable

Main I/O 1 Cable Keypad
Cable (Preinstalled)

Audio Patch Cord

Main I/O 2 Cable







**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

#### Bill of materials



Radio face plate Sonata 2012

Radio face plate Sonata 2011

Radio securing Brackets Flat ribbon rubber block

Mini Speaker with 1 screw

GPS antenna



Caution – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

#### Bill of materials



Main
Touchscreen
(Pre-installed in fascia Molding)

Fascia Molding



SD Card to USB adapter






TRIP Module with 2 screws

Bluetooth antenna preinstalled (Sonata 2011 only) External USB & SD Card Box (SD Card already inserted)



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

Bill of materials



Replacement radio flat ribbon (Sonata 2012 + only)

XM radio Antenna adapter





Clock / Temp Sensor/ Passenger warnings Module patch cord

TRIP Serial cable




**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

## Section 3 System Cable Connections and Identification



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Rear Backup Camera Cable - Main I/O 1

GPS Antenna Connection
– Main I/O 1



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



External Speaker

Connection – Main I/O 1

#### TRIP Serial Cable connection:

- 5 Pin to TRIP Module
- 3 Pin(Yellow, Red and Black) to
   MAIN I/O 1 Trip Serial cable
- 2 Pin(Blue and Green) to Audio
   Patch Cord






**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.




AUX Cable connection

– Main I/O 1

AV In connection – Main I/O 1 (optional)



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.




#### Audio Patch cord:

- AUX IN (previous page) to Audio Switcher input jack
- Steering wheel control wires (2 pin from TRIP SERIAL Cable (P:12).

Temp Sensor Serial MAIN I/O 1 to CLOCK/TEMP SENSOR/Passenger warnings Module patch cord (3 pins).




**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.




AV Out Connection – Main I/O 2

Note: Not required to connect to the device if AV OUT, IR Remote Control or Traffic tuner are not used.





**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Power connector for the CN-M5 Navigator coming **from the Audio Patch cord** 



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

# Section 4 Touchscreen Connection identification



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.






**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Main I/O Connection #1

SD/USB connection box to SD EXT connection



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Main I/O Connection #2




**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

# Section 5 Trip Module Connections and ports identification



Caution – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.






TRIP Module Dip
Switch location – For
Sonata 2011 only.
2012 & + does not use
DIP switches.
Switches are factory
preset but please
refer to the Appendix
1 at page 109 for
correct position.

TRIP Module interface connections


**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

#### Trip Module Connections/Cable identification





**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

## Section 6 Vehicle Preparation



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.




Identify the molding to be removed.

Protect the area with masking tape if needed. Carefully pry away the trim piece straight up starting at the back of the trim to gain enough to begin removing by hand. Insert a protected flat screw driver blade between the trim and the console where you see a small gap and pry upwards

When removing the trim piece it needs to be lifted vertically and pivot slightly to avoid damage. Do not force it, just carefully ease it.

**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Store these trim pieces carefully to avoid damage. Repeat the process for the other side.



Once both trim pieces are removed, the facia securing screws are exposed.
Remove both screws and reserve.



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Gently pry the black fascia that surrounds radio starting at the bottom ON BOTH SIDES where you just removed the screws. Gently unclip the surrounding towards to the top of the trim. Be careful to protect the surrounding dash trim.



Continue with fascia removal by gently prying the other side to free the panel from its retaining clips. Do not pull too far forward. Just enough to disengage the clips.



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



As you gently pull the panel forward disconnect the multi-way connector for the clock and airbag warning light located at the top of the trim.



Once the clock connector is disconnected pull the fascia further forward and disconnect the heater controls multi-way connectors (2). On vehicle with auto climate control gently pull the sensor tube off the the rear of the control. Do the same for the Hazard switch

**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.




Undo the 4 securing screws for the radio and store them safely.

Gently ease the radio forward and disconnect the **FM** and **XM** antenna and **ground** cable from the rear of the radio. Caution, press the locking tab after the pink plastic to disengage the XM antenna. A little flat screw driver may help.




**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



To free the radio completely disconnect the 2 multi-way connectors on the rear of the radio. Pressing the locking tab allows the connectors to be removed from the back.

**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.




Next step is to remove the storage pocket. Remove the 4 retaining screws for the storage pocket.



Please ensure that you locate the 2 lower difficult screws, save for reinstallation.



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.







#### For Vehicles with BlueLink

Please remove the 6 screws attaching the BlueLink module to the support bracket to allow for clearance to cut the radio support bracket

Once free, remove the silver brackets using a T15 Torx driver removing the 4 screws. These parts are not reused.

Caution – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.






The red arrows indicate the direction of cut and the area that needs to be trimmed. The factory radio will be located deeper in the dash than before to accommodate the new touchscreen and bezel mount.

**Be careful** to not cut electrical wires Follow the arrows direction of cut!!!!

Using a small saw (or any appropriate tool) trim the area marked to reflect the next step. This is necessary to allow the updated radio to be installed correctly. Clean the entire area with a vacuum to remove the plastic debris. Remove the 10mm nut that holds the trimmed piece.

**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Pry off the plastic antenna cables support with the help of a flat screw driver.



Use Vise grips carefully work the metal stud (circled) back and forth until it snaps off. Do the same with the metal support at the left. The metal support has to be removed completely at the welding point.

**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

## Section 7 Radio Preparation



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Remove existing radio back support using a Vise grip by unscrewing it counter clockwise.



Remove existing retaining brackets using a Phillips head screwdriver.
Secure the 6 countersink screws removed to be reused later.

**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

#### **Radio Preparation**



Remove the front panel retaining screw as shown. Repeat for the other side of the radio.



To detach the front panel completely from the radio, there are 6 retaining tabs that retain the radio panel in (2 on bottom, 2 on top and 1 either side). GENTLY lift these up a little (DO NOT SNAP THEM OFF) and pry the radio fascia clear enough to allow access to the cables on the rear.



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.


### Section 8 Vehicle Specific

2011 Sonata continue to next page.


2012+ Sonata jump to page 51



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.




Once the panel is free of the chassis, we need to remove the ribbon cable and the wireless antenna cable.




Notice the ribbon cable connection. There are locking tab cutouts on the ribbon cable to ensure the cable stays in place.

**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.




A little pressure is needed from a screwdriver to lift up the brown locking tab to allow the ribbon to freely be disconnected. Be gentle to avoid damaging the brown locking tab



Notice the red circles. The ribbon needs to be disengaged from the unlocked brown locking tab, to free it from the beige connector. Separate the white end from the lock by lifting gently. DO NOT PULL HARD

**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Once the ribbon disengages from the brown locking tabs gently remove the ribbon cable from the beige connector

Ribbon Cable disconnected – AT LAST!



Caution – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.






Disconnection of the wireless antenna is two handed process. There is a locking ring very close to the PCB (Printed Circuit Board) that needs to be disengaged (pulled up slightly) before pulling cable off the PCB. The cable and connector are very fragile.

Gently remove the Bluetooth antenna cable from the circuit board to allow complete removal.

**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.




After removal of the top screws the top panel is slid off the radio.



The front securing plate of the radio is mounted with a total of 7 screws. Two of these are hidden inside the top cover – as shown. Remove and store these.

**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



The front plate needs to be removed from the radio to allow the assembly of the new face place provided with the kit.
Remove the 5 retaining screws indicated and save for later use.



Install the TRIP interface module into the provided plate in the orientation shown. (White connector exposed on front of plate oriented away form CD tray, dip switches at rear)



Systèmes intégrés de navi-divertissement / Integrated navitainment sy

**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Secure TRIP interface module onto the bracket using the two philips screws provided.




DIP switches are factory set, do not change



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.







Gently feed the radio ribbon cable and Bluetooth antenna through the plate and locate the plate into the front of the radio. Be cautious to avoid causing any internal damage as the TRIP interface is pushed into the radio unit. CAUTION Sometimes the TRIP might snag a little on connectors, carefully maneuver into position.

Locate the new face plate in position using the embosses. Put the first 2 screws in diagonal to make sure the face plate is square with the radio and then screw the remaining 5 screws. At this point you can slide in the top cover and secure with 2 screws.




**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.






- 1- The **black** locking tab in the TRIP module is carefully lifted to allow the ribbon cable to be installed into the TRIP module.
- 2- The flat ribbon contacts (silver) need to be facing down (to make contact) and the blue needs to face up. The ribbon must be CAREFULLY but firmly pushed into the TRIP connector, ensuring it is parallel and has no bends or tears.
- 3- Then fold down gently the locking tab.
- 4- Then carefully install the rubber retainer, inserting the bottom piece first into place to ensure the locking tab and therefore ribbon cable does not disengage. Caution: Make sure to insert the bottom of the rubber block first otherwise the locking tab may fold back and brake. If the locking tab is broken; stop the installation immediately and contact support.

**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



The protruding curve of the ribbon cable must be CAREFULLY eased back into the radio unit (under the TRIP module), use just enough pressure to push into the radio.



Completed TRIP module ribbon cable installation.

**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

# After Completion of your Sonata 2011 radio preparation please jump to Page 63



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

## Sonata 2012+ Radio preparation and TRIP module installation



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.


There are 2 versions of radio's used in the 2012+ model. These are identified by the color of the connector. Brown or Black.

Both connectors require the supplied ribbon cable but have different methods of disengaging it.

If you have BROWN connector jump to next slide, if you have BLACK connector jump to slide 55.



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.




The cable needs to be disengaged from the unlocked brown locking tab of the radio body, to free it from the beige connector. **Lift the brown lever up** to unlock the ribbon. DO NOT PULL HARD, to avoid damage.

Once the brown lock is disengaged carefully lift the ribbon cable from the locking tabs and pull out.

Notice the contacts are facing upwards.



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



To install the supplied new ribbon cable. Insert into the connector fully (contacts side up above brown locking tab) then press the locking tab down. Note – A correctly installed cable has approximately 2mm of silver contact exposed. The new ribbon cable does not have the locking tabs like the one removed. Jump to page 57.




**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

## Sonata 2012+ Radio BLACK connector procedure



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.




The 2012+ Sonata requires a replacement ribbon cable to be installed into the radio. This is supplied in the kit. The locking tab for the ribbon cable is located facing out from the radio. With a small flat screw driver, lift up gently the locking tab, at this point the flat ribbon can be pulled to the inside of the radio and successfully removed.

Note – Silver contacts face down on this type of connector.

Locking tab in lifted position. Do not detach the flat ribbon from the factory face plate because it will not be reused.

**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Carefully push the replacement ribbon cable into the connector in the orientation shown and then lock down the tab to secure it in place. To ensure the ribbon is properly inserted, the blue section if the ribbon should stick out about 1/8" or 3mm from the connector.

**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.




Remove the 2 screws holding the CD player as indicated here and save these separately because they are smaller. Then remove the 5 screw surrounding the face plate

**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.




TRIP module correctly installed

Assemble the trip module with the supplied screws as indicated. The connector must face the face plate with the flat ribbon connector located at the left



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.







Run the flat ribbon thru the new face plate carefully. Make sure to not bend the flat ribbon.

Then assemble the new face plate and locate it using the embosses circled. Screw the face plate (3 screws) starting by the opposite corners to make sure the radio body is square.

Screw the CD player in place using the **bottom** holes with the small screws reserved separately.


**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.






- 1- The **black** locking tab in the TRIP module is carefully lifted to allow the ribbon cable to be installed into the TRIP module.
- 2- The flat ribbon contacts (silver) need to be facing down (to make contact) and the blue needs to face up. The ribbon must be CAREFULLY but firmly pushed into the TRIP connector, ensuring it is parallel and has no bends or tears.
- 3- Then fold down gently the locking tab.
- 4- Then carefully install the rubber retainer, inserting the bottom piece first into place to ensure the locking tab and therefore ribbon cable does not disengage. Caution: Make sure to insert the bottom of the rubber block first otherwise the locking tab may fold back and brake. If the locking tab is broken; stop the installation immediately and contact support.

**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.




The protruding curve of the ribbon cable must be CAREFULLY eased back into the radio unit (under the TRIP module), use just enough pressure to push into the radio.



Completed TRIP module ribbon cable installation.



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Attach the XM radio antenna adapter to the radio as shown




You have successfully retrofitted your factory radio!

**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.


### Section 9 Radio Bracket installation



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Attach the supplied replacement dash mounting brackets to the side of the radio using the countersink screws reserved previously. Check the alignment dimples (GREEN circles) labeled CDP to locate the brackets correctly Thread length of the screws are long enough to secure the radio properly.



NOTE – Look at the orientation of the brackets, the cut off corner is at the top. Repeat for the other side of the radio.

You have successfully prepared your radio.



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

## Section 10 Display Installation into Fascia

(If the screen has been pre installed into the fascia trim, please skip this section)



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.





Prepare the display for mounting into the new supplied fascia (if this was not completed already). Snug the screws up but do not tighten to allow for display adjustment once installed into fascia.

Install the display unit into the fascia. Take time to ensure that the alignment is correct by viewing the outside. Look to ensure the display is square and level. Tighten the fascia mounting screws to fix the display in that position.



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Apply LIGHT pressure to the back of the display to reduce any gaps between fascia and the display and then tighten the side screws. Check alignment and make minor adjustments as necessary.

The screen is preassembled from factory

**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Front of keypad



On rear of keypad install the control cable for connection to TRIP module.



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Touchscreen panel installed into replacement fascia. Recheck all screws, alignments and connections.

**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

### Section 11 Fascia Trim Preparation



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



To prepare the new fascia for installation some components from the old factory one need to be removed.

Remove the 4 screws holding the clock module and unsnap it from the fascia. Reserve for the final assembly.



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



To remove the each air vent requires the removal of 4 silver Phillips screws per vent.



Release the 2 plastic clips on the outside of the vent and 1 on the inside of the vent that retain the air vent to the factory fascia and carefully remove them.

**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Transfer the vent to the provided trim. Be careful to engage the guiding clip first as shown then snap in the surrounding clips. Once properly seated look for gaps on the other side of the fascia. If correctly assembled, proceed by screwing the 4 screws.



Repeat the process for the second air vent.

**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



To remove the hazard warning light switch requires pressing the retaining tabs on the rear of the switch and pushing the switch out towards the front of the panel



Once free of its locking tabs the switch just pulls forward

**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Remove the existing factory temperature control module from the original fascia (undo the 4 screws)

The temperature module is also retained by plastic retaining clips (3 in total, 2 on top and 1 underneath) Ease these forward to unlock the control and it will be free.

Relocate it to the new replacement fascia.



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Transfer the 6 white (or green) plastic clips from the old trim to the new trim. Pull side of clip gently and pull up. Install in carefully and securely onto new fascia.




**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

# Section 12 Lower Console Preparation



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



The lower storage cubby requires a little modification for the installation of the SD/USB interface box.

Unscrew the 4 screws indicated then unsnap the cover of the lower box

**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



The lower storage cubby requires a little modification for the installation of the SD/USB interface box. An area of plastic needs to be removed to allow the cable to exit the inside of the storage cubby.

After placing SD/USB interface box inside storage cubby, bring cable out of the rear to allow for connection later. Put back the top cover and 4 screws.



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Attach the SD/USB adaptor using 3M tape to the upper underside of the storage cubby.

Once completed the storage cubby looks like this with the SD/USB interface box installed.



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Reinstall cubby into dash unit carefully routing wires from rear to the radio compartment.



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

## Section 13 Electrical/Wiring Connections



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

#### In the following section we will:

- Prepare the radio patch cable and attach to the car & radio connectors
- Attach the clock / temp patch cable to the car harness and clock module
- Secure the clock module underneath the radio
- Video Tutorial about this section:

https://dl.dropboxusercontent.com/u/70065767/Manuals/Audio%20Patch%20Cord%20Assy.m2ts



Aux cable



Audio Patch Cord



**Factory Clock module** 

Clock / Temp Sensor/ Passenger warnings Module patch cord







Caution – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.




Attach the TRIP Serial cable 2 Pin connector to this connector to the Audio Patch cord as shown.

TRIP Serial cable





**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.




Attach the AUX cable male jack into the female of the Aux switcher board as shown. Secure in place with Electrical tape.

Reserve the White and RED RCA jack to be connected into the AUX cable from the MAIN I/O 1

Aux cable



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Connect the Audio Patch cord to the car matching connector as shown.




Connectors improperly seated.



Connectors properly seated. You should hear a **CLICK.** 

**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.




Reserve the CN-M5 4 pins square connector for the final assembly.

Attach the TRIP SERIAL to the MAIN I/O 1 TRIP SERIAL. (Ref: P:12)

Reserve the TRIP MOD cable for the final assembly. It will be plugged in front of the trip module (Ref: P:12)



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



This is Patch cord for the clock /Airbag/Seat Belt/Temp Sensor module

Plug into the car's 16 pins harness as shown at page 93.

Connector for the relocated Airbag / Seatbelt lights Page 94. Reserve for the final assembly.

Connect the TEMP SENSOR cable of the MAIN I/O 1 into the 3 pins socket. Reserve for the final assembly.

Plug into the factory Clock / Temp module (next page)



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Once wrapped, cut out the wrapping around the connector

Take the protective bag that your system came in. Cut enough material to wrap the module completely.




**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Clock Module Patch cord connected




**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Run the clock module cable 16 pin above and behind the metal tube

Bring the cable down



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.




Plug in the 16 pins clock module patch cord into the car harness.

Unplug and look for bent pins, if pins are bent, straighten back in position and plug / unplug / check again by caution.

Secure the clock module with electric tape with the other cables sitting at the bottom of the radio compartment



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Reserve the Airbag / Seat Belt cable for final assembly. The cable connects at the back of the facia under the keypad board



Caution – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

Mini speaker installation



Air vent support

Driver side kick near gas pedal

The recommended placement of the mini-speaker is located on the driver side. Follow up the side kick near the gas pedal, locate the plastic support in front of the feet air vent. Using the provided screw, attach the mini –speaker to the support bracket. The speaker is very light and require only one screw. Once completed, bring the wire to the head unit for final install.



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.


## Section 14 Installation into Vehicle




**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Approximate location of GPS antenna under the dashboard





Testing has shown that signal is very good at this point. Route the GPS cable over the right air duct.



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

#### **IMPORTANT**

Before proceeding to the final installation if you have purchased the following options, please proceed to their installation before completing the final assembly.

-	Backup Camera	Appendix 2 page 112
-	Parking Assist System	Appendix 3 page 115
_	RDS Traffic Tuner	Appendix 4 page 118



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.





#### For vehicles with BlueLink

Affix double sided tape and orient the swivel antenna's such that they are flat and once attached to the top the radio they must face right.

Temporarily support the BlueLink module underneath the dash board surface with the communication cable going to the left and ensuring the swivel antenna cables point right and are flat. This allows for clearance behind the radio. The Bluelink module will be affix on top of the radio when the radio body will be in place.



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Once radio is placed in position affix the Bluelink module (using the double sided tape) to the top of the radio about ¼" back from the front of the radio.


Caution – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

Prior to assembly of the trim to the car, please make sure you have at least the following connected properly .

- GPS Antenna to GPS Serial of MAIN I/O 1
- TRIP SERIAL cable to TRIP Serial of MAIN I/O 1
- TEMP SENSOR (Clock Patch Cord) to TEMP SENSOR SERIAL of MAIN I/O 1
- Mini Speaker to SPK of MAIN I/O 1
- AUX cable to AUX of MAIN I/O 1 (AUX should have been connected to factory AUX Audio Switcher at this point).
- OPTION
- CAMERA to CAMERA of MAIN I/O 1
- Audio Video Extension cord to AVIN of MAIN I/O 1 for external multimedia player
- Audio Video Extension cord to AVOUT of MAIN I/O 2 for read seat screen and sound
- IR Receiver for Infrared remote of MAIN I/O 2
- TMC cable to TMC Traffic receiver of MAIN I/O 2



Caution – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.





After ensuring all cables are correctly brought through to area beneath radio, attach:


- FM Radio antenna
- XM antenna
- Ground cable
- Multi-way connectors (2)
- Audio Patch cord goes into the first spot.

And install radio in dashboard. If the radio does not fit well in place, make sure there is no unnecessary cables and ensure they are well placed under the radio. You might need to bend the ground tab (back right) towards the radio to give more clearance.

Affix using the screws removed earlier.



Caution – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Prior installing the fascia, connect the TRIP cable to the TRIP module as indicated (5 PINS) and Parking Assist System cable (3 PINS) if purchased.

Getting ready to attach the new fascia trim, connect:

- The wireless antenna cable (Sonata 2011 only).
- Keypad green cable to the TRIP module.
- Air Bag / Seat Belt connector
- External media box (SD Card/USB)
- Main I/O 1
- Main I/O 2 (If needed)
- Air controls connectors (see next page)
- Hazard switch
- CN-M5 Power (4 PINS square)



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



#### Caution!!!!!

A/C Controls connectors and tube MUST be UNDER the metal cross beam shown.

Otherwise A/C system damage may occur. When putting the fascia in place, make sure wires are not squeezed between the A/C control panel and the metal cross beam.

**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

Install the facia temporarily in place and plug back the wires to the battery and test run the CN-M5 navigator.


Prior final assembly, test the following:

- Radio mode (TRIP): FM, XM, USB, AUX, CD Steering Wheel Controls and Voice Commands, etc... ALL functions supported by the factory radio.
- Facia keypad
- Navigation: Check for GPS reception (at least configure the basic settings on start-up)
- MP3 Player: See if you can select music from the File folder (refer to User Manual. Connect a USB thumb drive to the External Media box prior testing)

Once completed, you can proceed with the final assembly. Screw in place the new trim (2) Put back the remaining trim pieces.



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



VERSION: F:VP6.1/A:V1.05

1. Audio Configuration

BACO
O none B/T

2. Vehicle configuration
O YE Williamt
O 130

For proper radio operation, the correct car type needs to be selected.

Go into the CN-M5 Setting Panel, Select TRIP and at the bottom change accordingly as below.

Failing to do this may result in a TRIP.DLL FAILED TO LOAD message.

**2011 : Sonata - CAR TYPE 15** 

**2012+ : Sonata – <u>CAR TYPE 26</u>** 

For Sonata 2012+: Tick both selections as shown

then close

**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Place fascia carefully making sure you're not pinching or sharp bending any wires.

Align trim duct vents to the car one making sure you not remove the sealing foams then align the plastic clips to their holes. Press firmly the trim surrounding to snap the clips starting from the top. Then carefully move the next clips and apply firm pressure. Make sure the CD slot is properly aligned with the trim slot and look for apparent gaps.



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

#### YOU DID IT!





**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

Page Intentionally Blank




**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

## Appendix 1 TRIP Module DIP Switches (Sonata 2011 only)



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

Appendix 1: Trip module DIP switches (Sonata 2011 ONLY)



Please refer to the DIP switches selection guide located at the back of the TRIP module for proper operation.

#### **IMPORTANT**

DIP switches proper position are show by the black squares boxes NOT by the white crossed boxes.

Sonata 2011 DIP switches at their correct positions are show here.




**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

# Appendix 2 Backup Camera Installation



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.


Appendix 2: Backup Camera install



Attach the **BLACK** wire from MAIN I/O 1 "**REAR PWR**" to the radio front bottom screw as shown (**Ground**).



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Attach the RED wire from MAIN I/O 1 "REAR PWR" to the backup camera RED wire.

Plug the back up camera RCA jack into the same Yellow Camera jack of MAIN 1/O 1

**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

# Appendix 3 Parking Assist




**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

Appendix 3: Parking Assist System



OBD II Connector very simple.



Plug the other end into the Trip Module as shown

**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Plug the Parking Assist connector into the car's OBD located right underneath the driver crash pad in the middle. Once inserted, lock it in place by moving the yellow tab until you hear a "click".

Note: Please advise your dealer about this sensor and how to proceed to remove it.



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

# Appendix 4 RDS Traffic Tuner




**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.



Connect the male TMC FM adapter to the back of the radio. Reserve the white connector **MAIN I/O 2** for the final assembly.

Connect the female TMC FM adapter to the car male.





**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

#### Tips and tricks

To avoid over heating wire and connectors, it is recommended you use soldering acid Flux. This will greatly improve the quality of the soldering points. Before soldering, dip Into the acid flux paste the end of the soldering rod and apply a little flux to the wire section you wish to solder.



**Caution** – Documentation is an aid to successful installation. No liability is assumed for incorrect installation. If unsure of expertise required, please consult a qualified installation tech.

### **END**

